



## Thule 754 rapid system gutterless feet - changing locks



1 Insert the key and open the foot cover to reveal base of lock barrel.



2 Push the lock tooth down with your finger and hold.



3 Keeping your finger on the lock tooth, use your thumb to push the lock barrel.



4 You need to push the lock barrel as far as you can with your thumb.



5 Using your other hand take hold of the key and remove the lock.



6 Place the lock barrel at a 45 degree angle into the housing.



7 Push down into the housing until the tooth retracts and the lock barrel sits slightly recessed in the cover.



8 Turn the lock barrel 45 degrees anti clockwise and remove the key.



This leaflet has been produced by John Jordan Limited and is intended to supplement the manufacturer's instructions supplied. Please always follow the manufacturer's instructions. This advice is offered on the understanding that John Jordan Limited will not accept responsibility for any errors or omissions, or for any damage or injury incurred by choosing to follow any additional advice contained in this leaflet. Please always follow the manufacturer's instructions!

© These pictures and words are the copyright of John Jordan Limited trading as The Roof Box Company, all rights reserved.

[help@roofbox.co.uk](mailto:help@roofbox.co.uk)  
01539 621884